LOVED IN 70 COUNTRIES

pulsar NS200

BAJAJ

THE WORLD'S FAVOURITE INDIAN

Owner's Manual



To keep your bike in perfect running condition, please follow the periodic maintenance services which includes **3 Free and subsequent Paid services,** as per the schedule contained in this booklet.

अपनी बाइक को सही चलती हालत में रखने के लिए, कृपया आवधिक रखरखाव सेवाओं का पालन करें जिसमें **३ निःशुल्क और बाद में भुगतान सेवाएं शामिल हैं,** इस पुस्तिका में दिए गए अनुसूची के प्रति।

आपली बाईक परिपूर्ण स्थितीत चालू ठेवण्यासाठी कृपया या बुकलेटमध्ये दिलेल्या शेड्यूलनुसार पीरिऑडिक मेन्टेनन्स सर्व्हिसेचे अनुकरण करा. **यात 3 फ्री आणि त्यानंतरच्या पेड सर्व्हिसेस समाविष्ट आहेत**.

ನಿಮ್ಮ ಬೈಕ್ ಸಂಪೂರ್ಣ ಚಾಲನಾ ಸ್ಥಿತಿಯಲ್ಲಿರಿಸಲು, ದಯವಿಟ್ಟು ಈ ಕೈಪಿಡಿಯಲ್ಲಿ ನಮೂದಿಸಲಾದ ಶೆಡ್ಯೂಲ್ ನಂತೆ ನಿಯತಕಾಲಿಕ ನಿರ್ವಹಣಾ ಸೇವೆಗಳನ್ನು ಅನುಸರಿಸಿ. ಇವು 3 ಉಚಿತ ಮತ್ತು ನಂತರ ಪಾವತಿ ಸೇವೆಗಳನ್ನು ಒಳಗೊಂಡಿರುತ್ತವೆ.

உங்களுடைய பைக்கை மிக நன்றாக ஓடும் நிலையில் வைத்திருப்பதற்கு, இந்தக் கையேட்டில் கொடுக்கப்பட்ட அட்டவணையில் உள்ளவாறு 3, லவச மற்றும் தொடர்ச்சியான கட்டண சேவைகளை உள்ளடக்கிய காலமுறை பராமரிப்பு சேவைகளை தயவு செய்து பின்பற்றவும்.

మీ బైక్ చక్కటి రన్నింగ్ కండిషన్ లో ఉండాలంటే బుక్ లెట్లో ఉన్న షెడ్యూల్ ప్రకారం క్రమం తప్పకుండా మెయింటెనెన్స్ సర్వీసు చేయించండి, ఇందులో **3 ఉచిత సర్వీసులు, ఆ తర్వాత పెయిడ్ సర్వీసులు ఉన్నాయి.**

നിങ്ങളുടെ ബൈക്ക് തികഞ്ഞ റണ്ണിംഗ് കണ്ടീഷനില്സംരക്ഷിക്കാന്3 സൗജന്യവും തുടര്ന്ന് പണം നല്കിയുള്ളതുമായ മെയ്ന്റനന്സ് സര്വീസുകള്ദയവായി സമയാനുസൃതം ഈ ബുക്ക്ലറ്റിലെ ക്രമപട്ടികയില് കാണിച്ചപ്രകാരം പാലിക്കുക.

आपनार बाइक निर्भुलभावे चालू अवस्थाय़ राखार जन्य, निर्दिष्ट समय़ अन्तर रक्षणावेक्षण परिषेवा अनुसरण करून यार मध्ये आछे ३टि विनामूल्ये एवं परवर्ती मूल्याभित्तिक परिषेवा, एই पुस्तिकार अन्तर्भुक्त तालिका अनुयाय़ी।

ଆପଣଙ୍କର ବାଇକ୍‌କୁ ଉପଯୁକ୍ତ ରନିଂ ଅବସ୍ଥାରେ ରଖିବା ପାଇଁ ପିରିଓଡିକ୍ ମେଂଟେନାନ୍ସ ସର୍ଭିସ୍‌କୁ ଅନୁସରଣ କରନ୍ତୁ ଯେଉଁଥିରେ ଅନ୍ତର୍ଭୁକ୍ତ ରହିଛି 3 ଟି ମାଗଣା ଓ ପରବର୍ତ୍ତୀ ପେଡ୍ ସର୍ଭିସ୍ ଯାହାର ସିଡ୍ୟୁଲ୍ ଏହି ବୁକ୍‌ଲେଟ୍‌ରେ ପ୍ରଦାନ କରାଯାଇଛି ।

તમારી બાઇકને સંપૂર્ણ ચાલુ સ્થિતિમાં રાખવા માટે, કૃપા કરી નીચે મુજબ સમયાંતરની જાળવણી સર્વિસનું પાલન કરો જેમાં **૩ મફત અને પછી ચૂકવણી સર્વિસનો સમાવેશ થાય છ,** આ પુસ્તિકામાં સમાવિષ્ટ સમયક્રમ મુજબ

ਆਪਣੀ ਬਾਈਕ ਨੂੰ ਚਲਦੀ ਹਾਲਤ ਵਿੱਚ ਰਖਣ ਲਈ , ਕਿਰਪਾ ਆਵਰਤੀ-ਸੰਭਾਲ ਸੇਵਾ ਦਾ ਪਾਲਨ ਕਰੋ ਜਿਸ ਵਿੱਚ **3 ਮੁਫ਼ਤ ਅਤੇ ਬਾਦ ਵਿੱਚ ਭੁਗਤਾਨ ਸੇਵਾਂਵਾ ਸ਼ਾਮਲ ਹਨ,** ਇਸ ਕਿਤਾਬ ਵਿੱਚ ਦਿੱਤੇ ਗਏ ਅਨੁਸੂਚੀ ਦੇ ਪ੍ਰਤਿ।

আপোনাৰ বাইকখন সঠিকভাৱে চলি থকা স্থিতিত ৰাখিবলৈ, অনুগ্ৰহ কৰি নিয়মীয়া তত্বাৱধান সেৱা অনুসৰণ কৰিব য'ত অন্তৰ্ভুক্ত থাকে **3 টা বিনামূলীয়া আৰু তাৰ পিছৰ পৰিশোধ কৰা সেৱা,** এই পুস্তিকাখনত অন্তর্ভুক্ত অনুসূচী অনুসৰি ।

اپنی بائیک کو بہترین رننگ حالت میں رکھنے کے لیے، برائے مہربانی وقت وقت سے مینٹیننس کی خدمات پر عمل کریں جس میں شامل ہیں: اس کتابچہ میں دئے گئے وقت کے مطابق 3 مفت سروسز اور بعد کی پیڈ سروسز۔

FOREWORD

Welcome to the Pulsar family!

You are now the proud owner of the next generation **Pulsar NS200 BSVI**, India's No.1 sports bike. By No.1 we are talking about unparalleled performance, superior technology and incredible market leadership that Pulsar today enjoys. This makes the Pulsar you ride, unbeatable and unchallenged both on and off the road.

Before you ride out, please read this Owner's Manual carefully and familiarize yourself with the operating mechanism, controls and maintenance requirements of your Pulsar. This will ensure you a safe and trouble free ownership experience.

To keep your bike in perfect running condition and deliver consistent performance, we have specially programmed the periodic maintenance services which includes 3 Free and subsequent Paid services, as per the schedule contained in this booklet. We earnestly advise you to avail all these services at any of our Bajaj Dealers or Authorised Service Dealers (ASD), who are well equipped with all necessary facilities / genuine parts / oil and trained manpower to ensure the best care for your Pulsar. Your **Pulsar NS200 BSVI** comes with a warranty of **5 Years or 75,000 Kms** whichever occurs earlier from the date of sale. For details please refer to "Warranty : Scope & Limits" given in this manual.

Should you require any additional information feel free to contact us on helpline numbers or e-mail us at: **customerservice@bajajauto.co.in** or visit the Bajaj Auto website www.bajajauto.com

To be a part of the Pulsarmania, visit **https://www.bajajauto.com/bikes/pulsar** and follow Pulsar on Instagram at **@mypulsarofficial.**

Rev up, shift gears and enjoy the Pulsar experience…

SERVICE DEPARTMENT
BAJAJ AUTO LIMITED

TABLE OF CONTENTS

Description

1. Technical Specifications..... 1
2. Identification Data 4
3. Location of Parts 5
4. Steering cum Ignition lock.....6
5. Fuel Tank Cap.....7
6. Instrument cluster Details 8
7. Bajaj Ride Connect.....22
8. Control Switches 24
9. Mobile Charger, E20 Petrol & EBA 26
10. Antilock Braking System..... 27
11. Pillion Seat / Tool kit 28
12. Rider Seat / Battery 29
13. Fitment of Rider & Pillion seat..... 30
14. Daily Safety Checks 31
15. How to ride your Bike 32
16. Safe Riding Tips 36
17. Engine Oil 37
18. Tubeless Tyre & Tyre pressure..... 38
19. Battery..... 39
20. Engine Cooling system..... 40
21. Coolant..... 41
22. Periodic Maintenance Information 42
23. Brake Fluid 44
24. Vehicle Cleaning and Washing Care..... 45
25. Monsoon Care..... 46
26. Free Service Guidelines 47
27. Periodic Maintenance & Lubrication Chart..... 48
28. Non Use Maintenance 56
29. Delivery Certificate 57
30. Warranty : Scope & Limit 58
31. Battery Warranty Card 61

Safety and Warning information :

Warning :

This indicates that a potential hazard or injury to you or other persons & to the vehicle can happen if advice provided is not followed.

Caution :

This indicates that a potential hazard that could result in vehicle damage. Follow the Advice provided with the caution.

Notice:

The description and illustration in this booklet are not to be taken as binding on the manufacturers. The essential features of the type described and illustrated herein remaining unaltered. Bajaj Auto Limited reserves the right to carry out at any moment without being obliged to bring this booklet upto-date & to do modifications on the vehicle, parts or accessories as may be convenient and necessary.

TECHNICAL SPECIFICATIONS

Parameter	Pulsar NS 200 BS VI
Engine	4 Stroke, Single Cylinder
Bore x Stroke	72 mm x 49 mm
Engine Displacement	199.5 cc
Compression Ratio	11.4 ± 0.5 : 1
Idling Speed	1500 ± 200 rpm
Max. Net Power	18.61 kW (25.3 PS) @ 10250 rpm
Max. Net Torque	18.1 Nm @ 8000 rpm
Ignition System	DC
Fuel System	Fuel injection System
Spark Plug	1 No.
Spark Plug Gap	0.8 ~ 0.9 mm
Lubrication	Wet sump forced Lubrication
Transmission	6 speed constant mesh
Gear shifting Pattern	1 Down 5 Up
Engine Cooling	Liquid cooled
Starting Aid	Electric starter
Front & Rear Brake	Disc Brake

TECHNICAL SPECIFICATIONS


Parameter	Pulsar NS 200 BS VI
Fuel Tank Capacity	
Full	12 Liters (No Reserve)
Dimensions	
Length	2017 mm
Width	820 mm
Height	1075 mm
Wheel base	1363 mm
Ground Clearance	168 mm
Front Tyre Size	100/80-17,52P Tubeless
Rear Tyre Size	130/70-R17 Tubeless
Tyre Pressure	
Front	1.75 Kgf/cm^2 (25 PSI)
Rear (Solo)	2 Kgf/cm^2 (28 PSI)
Rear (with pillion)	2.25 Kgf/cm^2 (32 PSI)
Electrical System	12 Volts DC
Battery	12V 8Ah VRLA
Head Lamp	LED
Tail / Stop Lamp	LED

Parameter		Pulsar NS 200 BS VI
Position Lamp		LED
Side Indicator Lamp		LED
Rear No. Plate Lamp		Bulb 12V,5W
Speedometer	Neutral Indicator	Display on TFT
	Hi-Beam Indicator	LED-Blue.
	Speedometer Illumination	TFT (5" Colour)
	Fuel Level Indicator	Display on TFT
	Malfunction Indicator	LED
	Coolant Temp. Indicator	Display on TFT
	Low Oil Pressure Indicator	Display on TFT
	Turn Signal Indicator	LED-Green
	Service Reminder	Display on TFT
	Side Stand Indicator	Display on TFT
	ABS Indicator	Display on TFT
Horn		12V DC
Vehicle Kerb Weight		158 kg.
Vehicle Gross Weight		308 kg.

Note : • All dimensions are under UNLADEN condition. • Above information is subject to change without any notice.
• This vehicle complies to BS VI standards. • AHO is government regulation.

IDENTIFICATION DATA

The Frame and Engine serial numbers are used to register the motorcycle. They are the unique alpha-numeric codes to identify your particular vehicle from others of the same model and type.



Frame Number Location
On RH Side of Steering Tube
(Alpha-Numeric - 17 Digits)

Engine Number Location
On LH Side Crankcase Near Gear
Change Lever (Alpha-Numeric - 11 Digits)




LOCATION OF PARTS



STEERING CUM IGNITION LOCK

Steering cum Ignition Lock :
It has three positions.



- **LOCK:** Steering locked. Ignition OFF.
- **OFF:** Steering unlock. Ignition OFF.
- **ON:** Steering unlock. Ignition ON.

To Lock the Steering : To lock the steering, turn the handle bar to the left side. Turn the handle bar to the left or right. Push & Rotate the key to "LOCK" position & remove the key.

Steering locking on handle position left hand side only.

To Unlock the Steering : Insert the key in steering cum ignition lock. Push & Rotate it clockwise to "OFF" or "ON" position.

Key : A common key is used for 'Steering cum Ignition lock', 'Fuel tank cap' & 'Rear Seat'.

"Cranking ON and OFF duration" control –

- During Engine crank cycle cranking is allowed only for fixed duration and in between successive cranks (in case engine does not start) here is a cooling off period.
- Cranking on-off duration control feature to avoid battery discharge-

- 1st Crank ON (5 sec) & Disable for 2 sec.
- 2nd Crank ON (5 sec) & Disable for 2 sec.
- 3rd Crank ON (5 sec) & Disable for 10 sec.

After a gap of 10 sec cranking cycle continues.

- **Starter disabled if side stand down** – With side stand down condition and vehicle in gear, Engine cranking is disabled through ECU.
- Headlight control on rpm – Headlamp will be turned ON only at Engine running condition.



Fuel Tank Cap

- There is no fuel cock.
- Always maintain minimum 3 Liter Petrol in fuel tank.
- Do not use adulterated fuel as it will result in rusting & clogging of Injector, Fuel pump module & catalytic Convertor.

Fuel Tank Cap


- To open the fuel tank cap, open the flap. Insert the key i n the lock and turn it clockwise and lift fuel tank cap.
- To lock the 'Fuel Tank Cap' insert the key in the lock and turn it clockwise and press fuel tank cap. 'Click' sound ensures cap is fully locked.

  Precaution : Dont attach metallic 'Key chain' as it may damage paint of petrol tank cover.

⚠ **Caution**

- In case petrol is spilled out on petrol tank, It is to be immediately cleaned with clean soft cotton cloth to prevent permanent stain marks on petrol tank.

INSTRUMENT CLUSTER DETAILS



Speedometer display will work when Ignition switch is in 'ON' position and Kill switch in "ON" position.

1. **Ride Modes:** Ride modes namely Sport, Road, Rain, OFF-Road and Tour are provided in this vehicle. Ride mode change can be done in any mode like, TRIP A or TRIP B.

   To change ride mode, press upward toggle switch (on LH control switch) for more than 3 seconds, Ride modes section becomes highlighted. Rider can toggle through the Ride modes using up/ down toggle buttons on control switch LH for selecting the desired Ride modes. Once the Ride mode is selected, press 'SET' button on control switch LH for enabling desired Ride mode.

   Ride Mode can also be accessed from Menu as:

   Menu ⟶ Settings ⟶ Ride Mode

   Rider is required to do Zero throttle to change the desired mode.

- After selecting required mode, rider should wait for system response:

a. If system accepts required mode, selected Ride mode will display on screen.

b. If system rejects required mode, then instrument cluster will show previous/ default mode.

Note: Bike has a default mode which is set to "ROAD".

- If any system related error is present, only in that case default mode will be activated.

Ride Mode selection while vehicle running:

Selection is accepted only in condition of Zero throttle.

Ride Modes:

A. Sport Mode:

- This mode is tuned for maximum performance, delivering a sharper throttle response and quicker acceleration.
- It enhances the bike's responsiveness, providing a more thrilling and engaging riding experience.

B. Road Mode: This mode is tuned to deliver balanced power for riding in mixed traffic conditions. It offers smooth performance and comfortable handling, ensuring an enjoyable riding experience while maintaining good fuel efficiency.

C. Rain Mode: This mode is tuned for optimal performance in slippery road conditions. It moderates power delivery and softens throttle response to improve traction and stability, prioritizing rider's safety in road conditions.

D. OFF-Road Mode: Specially made for broken road and village roads, giving good stopping ability with safety.

- It is designed to excel on challenging terrains, allowing for controlled sliding and enhanced maneuverability.
- ABS OFF-Road mode delivers minimum stopping distance with adequate tyre traction and braking stability on off-roads.
- Adaptability on all different bad road conditions and down hill ride.

E. Tour Mode: This mode is tuned to deliver balanced power for riding in mixed traffic conditions. It offers smooth performance and comfortable handling, ensuring an enjoyable riding experience while maintaining good fuel efficiency. This mode also gives option to track Trip distance and DTE for touring.

2. **Tachometer Bar:** It shows engine speed in rpm. Tachometer bar blinks if rpm is greater than 9000.
3. **Traction Control Indication (TC):** Traction control system avoids or limits the slipping of wheels on the roads or on slippery surfaces during the acceleration. TC icon glows when Traction control in activated.
   When vehicle speed is more than 5 km/h the Traction control indicator goes OFF, if this indicator glows while vehicle is running, it means there is a problem in Traction control system.
   Traction control can be switched off in "SPORT" & "OFFROAD" Ride Mode from Menu as:
   Menu ⟶ Settings ⟶ Vehicle ⟶ Traction Control
4. **ABS Indicator (ABS):** With Ignition switch ON the ABS indicator glows. When vehicle speed is more than 5 Km/h the ABS indicator goes off, if this indicator glows while vehicle is running, it means there is problem in ABS.
5. **MTC OFF:** It gets displayed when traction control is deactivated. When traction control is activated MTC OFF will disappear from instrument cluster.
6. **Missed Call Alert:** If your Smartphone is paired with the instrument cluster of the vehicle via bluetooth, then you will get the missed call alerts on the instrument cluster.
7. **Smartphone Battery level:** If your smartphone is paired with the instrument cluster of the vehicle via bluetooth, then it will display battery level of your smartphone on instrument cluster.
8. **Smartphone Network Range:** It will display network of your smartphone on instrument cluster of your vehicle when connected via bluetooth.
9. **Bluetooth icon on Instrument cluster:** It displays status of your smartphone pairing with your vehicle.
10. **Generic Alarm (⚠):** It glows in red color indicating "Low battery" / "Low oil pressure" / "High engine temperature" / "General warnings". Present warning can be confirmed in Notification Menu.
11. **Side Stand Indicator:** It gets displayed when side stand is down.

Side Stand Condition	Gear position	Remark
Down	Engine in neutral gear position	Self-start / kick start possible
	Shifting gear from 'N' to 1st gear in engine start condition by pressing clutch lever	Engine will get cut off
Down	Engine in gear position	Engine will not start by self-start / kick start.

12. **Digital Clock:** It indicates time in HH:MM (AM/PM).
13. **Turn Signal Indicator (⬅➡):** When Turn signal switch is pushed to Left or Right, Turn Signal Indicator - LH or RH will flash.

14. **High Beam Indicator ( ):** It glows when Headlight is ON & High beam is selected with engine running.
15. **Malfunction Indicator ( ):** It glows whenever any abnormality is noticed in functioning of FI system related components.
16. **Speedometer:** Vehicle speed will be displayed in digital form in km/h.
17. **Max. Acceleration Timer:** It displays timer for Maximum acceleration achieved (0~60 km/h). This detail is only available in Sport mode.
18. **Fuel Level indication:** It indicates available fuel in fuel tank. Instrument cluster shows warning messages in case of low fuel level.

    Fuel level sensor OPEN condition: "E, F & Fuel boundary" all three blinks.

    Fuel level sensor SHORT condition: "E, F, Fuel boundary & all fuel bars" all four blinks.
19. **Turn by Turn Navigation:**

    By default navigation is "OFF". To use navigation, your smartphone is to be paired with the instrument cluster of your vehicle via bluetooth. Rider can update from TBT Navigation to Map Mirroring mode only if Smarphone is paired with instrument cluster via bluetooth and Wi-Fi.

Default: OFF

Navigation can be turned "ON" from "Bajaj Ride Connect" App by entering destination. Based on turn, it will show turn details and navigation information.

Information display will show following information's while using Google Map navigation.

- "NO GPS" when smartphone GPS signal is not available.
- "REROUTING" when application is rerouting navigation.
- "DESTINATION" "REACHED" in when vehicle reached the desired location.
- Display will toggle between "ETA" (Estimated time of arrival) and "ETD" (Estimated travel distance).
- "TURN-XXXX" if any turn is ahead, "XXXX" if vehicle needs to go on straight and "UTURN-XXXX" if a uturn is ahead.

Note: Map will be available for 7 years only.

20. **Favorite Menu:** This is a dynamic selection menu and can be changed as per customer's selection from 'Favorite' menu.
21. **Odometer:** The odometer shows the total distance that the vehicle has covered. Odometer cannot be reset to 'Zero'.

22. **Ambient Light Sensor:** It controls instrument cluster brightness intensity and theme based on ambient light (only if brightness and theme selection is kept on Auto mode).
23. **Music Panel:** It displays music which has been played by the rider only if bluetooth is connected and music is played on connected phone.
24. **Gear Indication:** It will display gear position from 1 to 6. It will display N when vehicle is in neutral position.
25. **Position lamp Indicator ( ):** It Indicates Position lamp is ON.

Note : After switching 'ON' the ignition switch, the following indications will remain 'ON' till engine is started.


- Malfunction Indicator.

Instructions :

Incase Malfunction indicator, ABS indicator gets ON during vehicle running, bring the vehicle nearest BAL authorised workshop for inspection/ repair.


For displaying menu on instrument cluster screen, press 'SET' button of LH control switch for less than 1 sec.

Menu Options:



A. Information


a. Vehicle Info: Select vehicle info through toggle buttons on control switch LH and press 'SET' button to display vehicle information.




Press 'Exit' button on control switch LH to return from vehicle info menu option.

b. Trip Info: Select trip info through toggle buttons on control switch LH and press 'SET' button to display trip information.

1. Trip A/ Trip B: Select 'Trip A' to view trip details.



To reset 'Trip A', press 'SET' button for less than 1 sec, following screen will appear.




Select 'Yes' and press 'SET' button, 'Trip A' will get reset.

Press 'Exit' button on control switch LH to return from 'Trip A' menu option.

Similar steps to be followed to view or reset 'Trip B'.


2. Tour Info: Select Tour info through toggle buttons on control switch LH and press 'SET' button to display Tour info details.

Tour info will be updated only for the time vehicle is driven in Tour mode.




To reset 'Tour Info', follow same steps like 'Trip A' & 'Trip B' reset.

c. Lap Timer: Select Lap Timer through toggle buttons on control switch LH and press 'SET' button to display Lap Timer information.





1. Lap Timer: Lap Timer is OFF by default setting. To start Lap Timer, select 'Lap Timer' and press SET button on control switch LH for less than 1 second. Below screen will get displayed.




2. Lap Records: Lap Records are displayed in this screen, it stores multiple lap timing until reset. It also displays best lap timing among all laps.

It displays lap details when the desired lap is selected.







3. Reset Lap Records: This menu is used to reset all available Lap records.



d. Documents: If your smart phone is paired with the instrument cluster of the vehicle via bluetooth and Wi-Fi, then you can view the documents uploaded on Bajaj Ride Connect App in this section.







B. Navigation: By default Navigation is 'OFF'. To use navigation, your smart phone is to be paired with the instrument cluster of your vehicle via bluetooth.

Default: OFF


Navigation can be turned "ON" from "Bajaj Ride Connect" App by entering destination. Based on turn, respective segments will be ON & rest will be turned OFF.

Information display will show following information's while using TBT navigation:


- "NO GPS" when smartphone GPS signal is not available.
- "REROUTING" when application is rerouting navigation.
- "DESTINATION" in top & "REACHED" in bottom multi information display when vehicle reached the desired location.
- Bottom multi information display will toggle between "ETA" (Estimated time of arrival) and "ETD" (Estimated travel distance).
- Top multi information display will show "TURN-XXXX" if any turn is ahead, "XXXX" if vehicle needs to go on straight and "UTURN-XXXX" if a uturn is ahead.

Note: Map will be available for 7 years only.


Navigation can also be turned from instrument cluster menu for saved addresses, recent destinations and POIs (only incase bluetooth and Wi-Fi is connected.




Recent destinations





C. Music: If rider smartphone is paired with the instrument cluster of the vehicle via bluetooth and Wi-Fi and Music is played on connected Smartphone, Then rider will be able to do following action - Music volume up / down & pause, Play, Shift to next track.













D. Calls: Calls can be made to contacts from favourite and call logs if bluetooth is connected. This feature is only applicable for Android (not iOS)

a. DND: By activating DND, Rider will not receive any call on cluster screen till DND is turned OFF.



b. Favourites: List of contacts marked as 'Favourite' is displayed in this menu.




c. Call Logs: List of recent call logs is displayed in this menu.




E. Settings:

a. Personalisation:



1. Day/ Night Modes: Day, Night or Auto mode can be selected through this menu to adjust TFT screen themes.



If Night mode is selected, Dark theme will be applicable. If Day mode is selected Light theme will be applicable. In case of auto mode, theme will be adjusted as per ambient light.


Dark Theme




Light Theme




2. Quick Access: One option can be selected from the available menu in Quick Access which can be operated by user by pressing Down Toggle button for more than 3 seconds.




3. Favorites: One option can be selected from the available menu in Favorites which will be displayed in TFT screen near to Odometer reading.




4. Brightness: TFT screen auto brightness can be turned 'ON' or 'OFF'. If auto brightness turned OFF, brightness can be adjusted (Low or High) as per user requirement.






b. Ride Modes: Desired ride mode can be selected by user through this menu.



c. Connectivity: Using this menu rider can connect a smart phone with instrument cluster through Bajaj Ride Connect App.

PULSARXXXX is the broadcasting name for bluetooth connectivity and pairing of Bajaj Ride Connect App with instrument cluster.




d. Vehicle: Sport shift and Traction Control (TC) can be turned 'ON' or 'OFF' through this menu.

Sport Shift :


This feature allows to shift gear without pressing clutch lever. Sport shift is only available in Sport mode. When the rider changes the ride mode from Sport to any other mode, Sport shift will be turned OFF.

Incase Sport shift menu is accessed in Road, Rain or Off Road mode message will appear in Multi info display "CHANGE RIDE MODE TO SPORT".


Based on rider requirement, Sport shift feature can be deactivated or activated in Sport mode.




e. System Settings:




1. Date: Date is displayed in DD-MM-YYYY format and can be updated through this menu.




2. Time: Time is displayed in 24 HR or 12 HR format and can be updated through this menu.




3. System Info: It displays the instrument cluster and firmware bluetooth version details.



4. Factory Reset: Selecting this menu will erase all the saved data and reset to Factory Setting.



F. Notifications: It displays various warnings under this section.



BAJAJ RIDE CONNECT

Bajaj Ride Connect Application:

"Bajaj Ride Connect" Application is based on bluetooth connectivity with the instrument cluster. This app offers a range of features, including vehicle management, service booking, document storage and more. With seamless bluetooth connectivity to Pulsar, the app ensures a personalized and convenient riding experience for every register user.

Key features of the application:

Bluetooth: once connected to the vehicle through the application user can access below bluetooth features:

a. Call Accept/ reject with the help of Call button on control switch LH.
b. Smartphone battery level.
c. Smartphone network range.
d. Missed call.
e. Message alert.

Service:

a. Book service appointment for relevant service type.
b. Locate nearby BAL workshop location.

Document storage: Important vehicle related documents, such as insurance paper and registration certificates, can be securely stored within the app, providing easy access whenever needed.

⚠ Caution: Document storage works as a digital wallet and is only for storage purpose.

Reminders: Users can set reminder for vehicle maintenance, service schedules. insurance renewals and other important tasks.

Trip with Turn by Turn Navigation: The app provides comprehensive navigation services with voice guidance, allowing users to set multiple stops and reach their destinations conveniently. It allow users to record their trips, capturing valuable data such as distance, duration and route. Additionally, users can share their exciting journeys with friends and family.



BAJAJ RIDE CONNECT

Application download:


Bajaj Ride Connect application is available in the Google play store (for android) or Apple store (for iOS).


- Download the "Bajaj Ride Connect" App from Google play store/ Apple store.
- Click on "Sign up" to register in the App with your registered mobile number.
- Enter your personal details (first & last name).
- Enter VIN of your vehicle (VIN can also be scanned).
- Sign up in App
- Enter OTP.
- Login in App
- "Bajaj Ride Connect" App is ready to work.


Bluetooth connectivity:


Your vehicle is equipped with bluetooth connectivity feature by which you can pair your smartphone with instrument cluster of your Pulsar vehicle through "Bajaj ride connect" application.


- Turn the ignition switch and kill switch "ON".
- Login "Bajaj ride connect" application on your smartphone.
- For first time pairing, allow the application to access:
    a. Device's location if GPS is not enabled in your device.
    b. Access your phone called logs.
    c. Send and view messages.
    d. Notification's













CONTROL SWITCH - LH





A. Set Button: Set button is used for :
- Call Accept: Press Set button for less than 1 sec.
- Menu Selection: Press Set button for less than 1 sec.

B. Upward Toggle switch: It is used for
- To toggle towards upwards option in menu.
- Long press for 3 sec. to access Ride mode change option.

C. Exit Button: Exit button is used for:
- Call Reject: Press Exit button for less than 1 sec.
- Menu Exit: Press Exit button for less than 1 sec.

D. Downward Toggle switch: It is used for
- To toggle towards downwards option in menu.
- Long press for 3 sec. to access Quick selection menu.


E. Turn Signal Switch: When the turn signal knob is turned to Left (⇦) or Right (⇨) respective indicator will start blinking, to stop blinking push the knob in & release.

F. Horn Button ( ): Press button for sounding horn.

G Pass Switch: Press the switch to put 'ON' Hi Beam/ Low Beam/ Pass light. It is used to give signal to vehicles coming from opposite side while overtaking.

When headlight is ON, High or Low beam can be selected with this switch. Hi beam indicator light located on Speedo console will light up when high beam is selected.

: High Beam : Low beam



H. Hazard Switch: When hazard switch is pressed all 4 indicators will blink. Rider must only use vehicle hazard light when his vehicle is stopped in a hazardous position or rider is driving in hazardous conditions, such as rain or fog.

I. Engine Kill Switch & Starter Button: It is a combi-switch used for switching ON & OFF the engine and to start the vehicle.

It is recommended to start the engine with the transmission in neutral.

Vehicle in gear - Press clutch lever & operate starter button to start the engine.

: Engine OFF
: Engine ON
: Engine Start

J. Light Switch: It has 2 positions. When ignition switch is 'ON' & Engine is 'ON', lighting system will work as per given table.

●	: Tail lamp will get 'ON'. DRL 'ON' (High Intensity)
☼	: Head lamp, Tail lamp, Number Plate lamp & Position lamp will get 'ON'. DRL remains 'ON' (Low intensity)


Day Time Running Light Feature:

- Day Time Running light is provided inside headlamp.
- Day Time running light gets 'ON' (High intensity) when ignition switch turned to 'ON' position.
- After headlight is turned to 'ON' position with **engine running** intensity of DRL LED's will get reduced.

Igntion Switch	Light Switch	DRL	Head Light
ON	OFF	ON High Intensity	OFF
ON	ON	ON Low Intensity	ON

'C' Type Mobile Charger

- 'C' Type Mobile charging socket has been provided on instrument cluster flap.
- The charger socket has been provided with cap to protect charger socket from dust & water entry during washing/ during rain.
- Always ensure charger cap is firmly fitted on socket, when charger socket is not in use, during washing/ during rain.
- During washing, do not direct water jet towards charger socket.
- Do not use the charger socket in wet conditions to prevent permanent damage to the device or the bike's electrical system.
- Ensure charger socket is dry before using it.



- The mobile charger will supply output voltage only in engine running condition.
- Customer to use suitable charging cable for mobile charging.

⚠ **Caution:** Do not use mobile phone while driving. Momentary lapse in concentration might result in an accident.



E20 :

- This vehicle is compatible for "E20" Petrol i.e. Petrol blended with 20% Ethanol. E20 sticker affixed on fuel tank cap.
- In this vehicle 'E10' Petrol (existing) i.e. Petrol blended with 10% Ethanol also can be filled.


Emergency Brake Alert

- An Emergency Brake Alert (EBA) is an active safety feature that automatically flashes the brake lamps during sudden, hard braking.
- During this sudden braking, the brake lamps flash at high frequency to grab immediate attention of trailing motorists and prevent rear-end collisions.
- Highly visible flashing pattern pierce through low-visibility or heavy traffic conditions much faster than a standard brake light.
- This gives an explicit and unmissable cue that a panic stop is happening, drastically lowering the chance of rear-end hit.

ABS System

- Dual Channel ABS System is fitted in Pulsar NS 200 BSVI vehicles .
- Dual channel ABS means ABS is fitted on front & rear wheels.
- Always maintain a safe distance between you and objects ahead. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for motorcycle equipped with an anti-lock braking system may be longer than for those without it on rough road conditions. During these conditions the vehicle should be driven at reduced speeds
- When you apply Front brake / Rear brake by pressing Front brake lever / Rear brake pedal under conditions which may lock the wheels, you feel a corresponding sensation (pulsation) in Front brake lever/ Rear brake pedal. (as applicable to model) This is normal and it means ABS is active.
- ABS technology requires the rider to brake appropriately to ensure safer braking specially under acute conditions.
- Also it is recommended to use both front and rear brakes simultaneously.
- Always slow down when cornering. The anti-lock brake system cannot prevent accidents resulting from excessive speeds.
- Never drive by disconnecting wheel speedometer cable.

PILLION SEAT / TOOL KIT



Removal of Pillion Seat

- Insert Key into lock (A)
- Turn the key clock wise.
- Lift front end of 'Rear seat'
- Pull 'Pillion seat' toward front side.
- Take out 'Pillion seat'.

Tool Kit Location


- It is located below the 'Rear seat'.
- 2 rubber straps are provided to hold the tool kit.

⚠ **CAUTION :** Always fit rubber strap for locking tool kit.



First Aid Kit Location

- It is kept inside seat cowl RH side.




Removal of Rider Seat

- First remove 'Pillion seat'.
- Remove 'Rider seat' mounting bolts (B).
- Pull backward rear end of 'Rider seat'.
- Take out 'Rider seat'.

Battery

- It is located below 'Rider seat'.



FITMENT OF RIDER & PILLION SEAT



Fitment of 'Rider Seat'

- Match the bracket of 'Rider seat' (A) with slot (B).
- Push 'Rider seat' toward petrol tank.
- Match 'Rider seat' rear brackets (C) with the holes (D) provided on chassis.
- Tighten the bolts (E).

Fitment of 'Pillion Seat'

- First make sure 'Rider seat' is fitted properly.
- Ensure 'Tool kit' is located properly.
- Place 'Pillion seat' on fitment location.
- Match the bracket of 'Pillion seat' (H) with Hook (I).
- Insert lock rod (F) of seat into hook (G).
- Press front portion of seat.

Before riding motorcycle be sure to check following items. Please give proper importance to these checks and perform all of them before riding motorcycle.

If any irregularities are found during these checks, refer to the Maintenance chapter & see your dealer for the action required to return the motorcycle to a safe operating condition.

⚠ **Warning:** Failure to perform these checks every day before you ride may result in serious damage or severe accident.

- Enough **fuel level** for planned distance of journey. No fuel leakage in fuel lines.
- **Engine oil** level (between upper and lower level mark)
- **Throttle cable** play of 2 ~ 3 mm. Smooth operation and positive return to closed position,
- **Brake Fluid** level above MIN mark provided on reservoir, applicable to disc brake vehicle.
- **Drive Chain** slack of 15~25mm adequately lubricated.
- Function of all **lights & horn**
- **Clutch lever** play - 2 to 3 mm
- Check **Coolant level** between MIN and MAX mark in coolant reservoir tank.
- Smooth **steering movement** without restriction.
- **Side stand** return to It's fully up position.
- **Center stand** return to it's fully up position.
- Correct **inflation pressure** in both tyres. Adequate tyre tread depth - no cracks / cuts.
- Correct **rear viewing** span adjustment of mirror.
- Cleaning cloth not to be kept in vicinity of high temperature zone e.g. Radiator, engine, silencer assy, starter motor etc.
- Cleaning cloth to be strapped along with tool kit under rear seat assy.



1. Starting The Engine:

- Ensure minimum 3 liters petrol is available in fuel tank.
- Turn ignition switch key to '❷' position.
- Put kill switch in '↺' position.
- Confirm that transmission is in neutral/ press the clutch lever if transmission is in gear.
- Keep throttle closed & press starter button,
- Release starter button as soon as engine starts.

"Cranking ON and OFF duration" control –

Cranking ON-OFF duration control feature to avoid battery discharge-

- 1st Crank ON (5 sec) & Disable for 2 sec.
- 2nd Crank ON (5 sec) & Disable for 2 sec.
- 3rd Crank ON (5 sec) & Disable for 10 sec. After a gap of 10 sec cranking cycle continues.

Note

- The motorcycle is equipped with a clutch switch. This switch facilitates engine starting in neutral and gear position.

Gear Position	Clutch lever position
Neutral	Released
Gear	Fully pressed

- Incase of battery discharged condition please bring the vehicle to Bajaj Authorized workshop for repairs.

2. Shifting Gears:

- Close throttle and press the clutch lever fully.
- Shift into next higher or lower gear.
- Open the throttle and release the clutch lever slowly and simultaneously.



Gear shifting pattern

3. Moving Off:

- Check that side stand is up.
- Press the clutch lever.
- Shift into 1st gear.
- Open the throttle and release the clutch lever slowly and simultaneously.
- As the clutch starts to engage, open the throttle a little more, giving the engine just enough rpm to keep it from stalling.

Recommended Speed for Shifting Down

From 6th to 5th Gear	54 km/h
From 5th to 4th Gear	45 km/h
From 4th to 3rd Gear	35 km/h
From 3rd to 2nd Gear	25 km/h
From 2nd to 1st Gear	15 km/h

⚠ Warning

When shifting down to lower gear, do not shift at such high speed that engine rpm jumps excessively. This may cause engine damage, & rear wheel may skid. Downshifting should be done at recommended speeds as shown in table above.

4. Braking:

- Close the throttle completely, leaving the clutch engaged (except where shifting gears) so that the engine braking will help slow down the motorcycle.
- Shift down one gear at a time so that you are in Neutral when you come to a complete stop.
- When stopping, always apply both brakes at the same time.

5. Stopping the Vehicle :

- Close the throttle completely.
- Shift the transmission into neutral.
- Bring the vehicle to complete stop.
- Turn the ignition switch off.

6. Parking Using Side Stand:

- Support the motorcycle on a firm level surface with the side stand.
- Lock the steering on LHS.

⚠ **Caution:** Do not park on a soft or steeply inclined surface or the motorcycle may fall over.

7. Running IN

Proper running-in is important for the better life & trouble free performance of the vehicle.

- During first 2000 kms running-in period do not exceed following speed limits.

Kms	1st	2nd	3rd	4th	5th	6th
0 - 1000	10	20	30	40	50	60
1000 - 2000	20	30	40	50	60	70

- Always keep speed below the limits given in table.
- Do not REV the engine excessively.
- Do not start moving or REV the engine immediately after starting. Run the engine for a minute at idle speed to give the oil a chance to work up into the engine.

⚠ **CAUTION**

Always ensure side stand is UP while starting off.

Starter will be disabled if side stand down – With side stand down condition and vehicle in gear, Engine cranking is disabled through ECU & 'side stand down' Indication will be displayed in speedometer.

- Do Not REV engine in standstill condition.
- This vehicle has new 'Assist & Slipper' (A & S) clutch. Due to this, very little force is required for clutch lever operation. You won't feel jerks while sudden downshifting. Slight pulsation is felt at clutch lever. This is normal & indicates "A & S" clutch is working well.
- If engine coolant temperature crosses 110°C, 'Coolant Temperature high' alarm message will be displayed on primary speedometer indicating engine is overheated. **If vehicle is further driven in such a condition coolant temperature will increases up to 115°C & ECU will not allow engine to run above 4500 RPM.**
- Always maintain engine oil / coolant level between MIN & MAX mark at vehicle upright position on level surface.

Ensure following maintenance points to get optimum performance from your bike.

Fuel	Always maintain minimum 3 Liter Petrol in fuel tank.
Spark Plugs	Inspect and clean spark plugs. Adjust electrode gap. Replace spark plugs as per P.M. Chart.
Air Filter	Replace as per Periodic Maintenance Chart.
Engine Oil	Check engine oil level. Always use recommended grade and quantity.
Brakes	Ensure that the brakes are not dragging / binding.
Clutch	Ensure correct clutch lever play.
Tyre Air Pressure	Always maintain recommended tyre pressure.
Brake Fluid	Always maintain brake fluid level above minimum mark. Ensure no leakage of brake fluid in brake system.
coolant	Always maintain coolant level between minimum & maximum mark. Ensure no leakage of coolant in cooling system.

Fuel Saving Tips :

A well maintained vehicle and good driving can contribute a lot to the saving of petrol. Following are a few simple fuel saving tips.

- Ride smoothly and steadily at an optimum driving speed to get best mileage.
- Avoid harsh braking.
- Change the gear judiciously according to the speed and load requirement.
- Don't overload the vehicle above the specified payload.
- Use the accelerator judiciously.
- Cut off the engine if you want to stop for more than two minutes.

How to check mileage (Fuel efficiency)

Best way to calculate mileage is by following the full tank to full tank method.


- Fill way tank full up to small mouth (brim).
- Run the bike for say 100 km.
- Fill the tank full again in same fuel filling station, probably with same fuel dispenser.
- Divide kilometer run / fuel quantity filled.

SAFE RIDING TIPS

•Always wear Helmet while driving or riding. Your helmet should conform to Indian standards.
•Read thoroughly the instructions given in this manual and follow them carefully.
•Avoid unnecessary accessories for the safety of both rider and other motorists.
•Get familiar and follow traffic rules & regulations in your states as well as general traffic signs.
•Familiarise yourself well with starting, acceleration and braking of the vehicle.
•When applying the brakes, use both front & rear brakes simultaneously. Applying only one brake may cause the vehicle to loose control.
•Riding at proper speed, avoiding unnecessary acceleration and braking are important for safety, low fuel consumption and longer life of the vehicle.
•During monsoon, drive vehicle more cautiously. Remember vehicle skid more easily during light showers.
•Keep both hands firmly on handle bar & both feet securely on rider footrest. Do not take away both hands & / or feet from resting area as this is very unsafe.
•Do not use mobile phones while riding as it could lead to fatal accident.
•It is suggested to customer to take appropriate care in area of heavy monsoon or high rainfall area. The appropriate surface preventive coat to avoid rusting / poor surface finish on account of adverse atmospheric conditions.
•Always carry vehicle registration & insurance papers, and a valid driving licence with you.

General Maintenance Tips :

•Vehicle cleaning to be done with soft & clean wet cloth to avoid scratches on painted parts.
•Clean & lubricate all the important parts as detailed in a periodic maintenance chart.
•Do not apply direct water jet on painted, electrical / electronic parts.
•Do not obstruct engine cooling by adding mud protection sheet from front
•Drive cautiously. Start early & reach your destination safely.
•Avoid driving on loose sand or stones where vehicle is likely to skid.
•Properly wrap-up loose clothes while driving or riding to avoid entangling in wheel or other objects on road.
•Always concentrate on riding for safety.



A : Oil Filler Cap
B : Oil Level Gauge

Engine Oil Level Checking:

- Check engine oil level every day. Park vehicle perpendicular to the ground on level surface.
- Check oil level through oil level gauge 'B'.
- Always maintain engine oil level between upper and lower mark provided on Cover RH. Top up with specified grade of oil if the oil level is below lower level mark.

Engine Oil Capacity:

- Refill at servicing : 1200 ml.
- During engine overhaul : 1400 ml.

Recommended Engine Oil:

Always insist on Bajaj Engine Oil for optimum engine performance and warranty benefits. It is a specially formulated oil for Bajaj vehicles.

Model	Recommended Engine oil
Pulsar NS200	Bajaj 20W50 **BS6 Compliant** SAE 20W50 JASO 'MA2' API SN

- **Engine oil replacement frequency : 1st service & then every 10,000 Km.**
- **Engine oil level top-up frequency : Every 5000 km.**
- **For all BS VI Vehicles, above BS VI compliant engine oil is to be used only. Use of BS 6 engine oil will give prolonged life of catalytic convertor.**


⚠ **Caution:**

- It is most important to adhere to recommended grade & frequency of oil change for the purpose of long life of critical engine components. For details refer periodic maintenance chart.
- Do not reuse drained oil.

TUBELESS TYRE & TYRE PRESSURE

Tubeless Tyre :

The main advantage of tubeless tyres is in case of puncture the rate of air leak is very slow, hence customer can easily drive the vehicle upto nearest puncture repair shop for removing puncture.



Note:

Incase the motorcycle is fitted with imported tyres. compliance to respective Indian standard & central motor vehicle rules has been ensured.

Wheel Puncture:

- Visit nearest known tubeless tyre repair shop to remove puncture.
- Remove puncture by Filler or Plug method only.
- Do not use patch method to remove puncture of tubeless tyre.

⚠ **Caution:** Tubeless tyres are fitted in this motorcycle. The walls of the tyres in contact with the wheel rim should not be damaged in any way during fitment / removal of tyre. The tyre side walls in contact with wheel rim seals air.

Tyre Pressure:

Keep recommended tyre pressure (refer Technical Specifications) to increase life of the tyre & for better fuel consumption.

- Tyre warranty is settled by tyre manufacturer.
- Decision is taken based on tyre wear and running of vehicle.
- BAL settles tyre warranty for only imported tyres.



Battery : 12V - 8 Ah VRLA

- Battery is located below Rider seat.

Battery Features :

- No topping-up is required
- Reduced self discharge, Enhance safety.
- No vent tube open to atmosphere hence no discharge of electrolyte through vent tube.

.

⚠ **Caution:**

Do not drive / run vehicle in battery disconnected condition. It may lead to damage of electrical / electronic components.


- Environment care must be taken to dispose off the used battery.
- It is always recommended to hand over the same to the Authorised battery / BAL dealer for proper disposal of the same.
- When 'Low battery icon' pop-up in speedometer display, it is advised to reach BAL dealer & get it charged immediately.
- Warranty on battery is 18 months from the date of purchase of vehicle.


How to keep battery healthy ?


- Switch 'Off' ignition when engine is not running.
- Get battery checked/ charged during periodic services.

- Do not add extra electrical accessories such as - Remote, Bigger Horn, Musical brake light etc. This will reduce life of battery & may damage ECU.
- Disconnect battery +ve & -ve wires if vehicle is to be stored for more than 2 weeks. This avoids self discharge.

ENGINE COOLING SYSTEM







- Coolant is provided for cooling of engine.
- Water pump in the engine circulates the coolant in cooling system.
- The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap (A).
- Heat expansion causes excess coolant to flow into expansion tank (B).
- When the coolant temperature drops, this surplus coolant is sucked back into the cooling system.
- Cooling fan is provided for cooling of coolant circulated through radiator fins.

Note:

Fan will start at temp 95°C and stops at 90°C. This is normal condition & it indicates cooling system functioning well.

⚠Warning:

During operation, the coolant gets very hot & is under pressure. In case of scalding, rinse immediately with lukewarm water. Do not remove radiator cap, radiator hose or other cooling system components when the engine is hot. Allow the engine & cooling system to cool down.



Warning:

Coolant is poisonous and causes health hazard.

Avoid contact between coolant & skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor.

Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come in contact with coolant. Keep coolant out of the reach of children.

Coolant Specifications :

Use antifreeze ready to use "Bajaj Koolex" coolant only.

Total coolant quantity:


1000 ml.

(750~780 ml in radiator & 220~230 ml expansion tank).



Coolant Top up


- Park vehicle perpendicular to the ground on level surface by using side stand.
- Check coolant level in engine cold condition only.
- Ensure coolant level is between Min & Max mark.
- Always top up coolant through expansion tank cap (A).
- Always replace coolant with "Bajaj Koolex" coolant only.
- Use nitrile rubber hand glows while draining & topping up coolant.
- Do not top up coolant through radiator cap.



Spark Plug


- Remove spark plug by using plug spanner.
- Clean the spark plug.
- Adjust the gap if incorrect by bending outer electrode carefully.


Spark Plug Gap:0.8 to 0.9 mm.



Drive Chain Slackness

- Chain slackness will have to be adjusted whenever required.
- Std. Chain slackness 15 ~ 25 mm.
- Marking on chain adjusters should be identically positioned on both sides.





Drive Chain Cleaning



Drive Chain Lubrication

Drive chain must be cleaned & lubricated as per periodic maintenance schedule.

Drive Chain (Sealed type)

- 'O' rings must always be kept wet for best performance hence lubricate every 500 Km.
- Sealed chain lubrication can easily be done by owners using Bajaj 'Chain Lube Spray Can' available with BAL dealers.

Method of sealed type Chain Lubrication :

- Park vehicle perpendicular to the ground on level surface. Clean the chain by using lint free cloth (If excessive mud / slush found approach Bajaj Service Center for proper cleaning)
- Shake the can vigorously by holding vertically upright till the noise of steel ball inside heard uniformly.
- Hold spray can at the back of rear sprocket with extension tube nose at 5~10 cm.
- Rotate the wheel in reverse direction & spray the lube on middle portion of the chain up to full length of the chain.

BRAKE FLUID



Front Brake Fluid Reservoir



Rear Brake Fluid Reservoir

Front & Rear Brake Fluid Level

- Front brake fluid reservoir is located on RH side of Handle bar.
- Rear brake fluid reservoir is located behind RH pillion holder bracket.
- To check the brake fluid level, Park the vehicle perpendicular to the ground on level surface with handle bar in straight ahead condition.
- Always ensure that brake fluid level is above 'MIN' mark given on inspection Window.
- Incase of level drop, use only DOT-4 brake fluid (from sealed container) for top up & replacement.

VEHICLE CLEANING AND WASHING CARE

Regular cleaning not only enhances the appearance of your motorcycle but also plays a crucial role in maintaining its performance and extending its life by preventing rust, corrosion, and premature wear. We recommend following the guidelines below:

Washing Preparation:

- Ensure the engine and all hot components have completely cooled.
- Cover sensitive parts such as the muffler tail end, speedometer, headlamp, tail lamp, Indicators and control switches to prevent water entry and avoid damage or fogging.

Washing Instructions:

- Rinse the vehicle with clean water using a low-pressure spray to remove loose dirt and debris.
- Avoid spraying water directly on electrical, electronic components, the Oil cooler, lights, switches, or the muffler.
- Use a neutral pH bike cleaner; avoid harsh chemicals or household cleaning agents.
- Clean surfaces gently with a sponge or soft brush to prevent scratches.
- Rinse and wipe using a clean microfiber cloth, followed by thorough drying with low air pressure.
- Ensure all electrical connections are clean and moisture-free.
- Lubricate the drive chain and other moving parts after washing and drying.

Important Do's & Don'ts:

- Recommended washing pressure is up to 20 bar; maintain a 2-meter distance and avoid directing the jet at any spot for more than 10 seconds to prevent damage to electrical components like LCDs, LEDs, and other sensitive parts.
- Do not spray water into the air cleaner or throttle body, as it may cause starting issues.
- Avoid removing the seat or any other components during pressure washing to prevent water ingress.
- After washing, gently apply brakes at low speed to dry them; clean brake discs or pads if necessary.
- For matte-painted surfaces, avoid using wax or polish. Instead, clean with mild detergent and a soft cloth.

⚠ **Note :** Headlight lenses may temporarily fog up after washing or riding in the rain. This is normal and does not affect functionality. However, if the moisture/water accumulation is high, please visit the nearest BAL dealer for vehicle inspection.

Following these simple steps will help keep your motorcycle in excellent condition and ensure its reliable performance.

MONSOON CARE

Monsoon Care Tips for Your Vehicle

Avoid riding through deep water, as it may cause water ingress into the engine and electrical components, leading to damage.

If your vehicle gets submerged or stops while riding through water, do not attempt to restart it. Take it to the nearest Bajaj workshop for inspection.

Ride cautiously on wet roads. Avoid sudden acceleration, braking, or sharp turns. Use both brakes gently and ensure your tyres have adequate tread and correct air pressure.

Keep the brakes clean and dry. Mud and slurry deposits can lead to premature brake lining wear.

After riding through mud or slurry, wash and dry your vehicle thoroughly especially the metallic parts, underbody, and wheels, to prevent rust.

Clean and lubricate the drive chain frequently during the monsoon to prevent rust and ensure smooth performance.

Warranty Exclusions

Damages due to natural calamities like floods, fire, earthquakes, lightning, or any other act of God are not covered under warranty.

Failures resulting from external conditions such as water ingress due to riding through water, or premature wear of brake pads or discs caused by prolonged exposure to slurry (Muddy water) are not covered, particularly during the rainy season.

Note:

Headlight, tail lamp, or blinker lenses may temporarily fog up after rain or washing. If excessive moisture or water accumulation persists, please visit the nearest Bajaj dealer for inspection.

Instruction to avail Free Service through Digitized Free Service Coupon

Please follow following procedure : -

- Please provide your mobile number to Dealer at the time of buying of new Bajaj Vehicle.
- In case of change in mobile number, please update to Dealer / ASD.
- When you are at Dealership / ASD workshop for availing Free Service, you will receive the 'Unique Coupon Number' (UCN) through SMS in your mobile.
- Please inform the UCN to Dealer / ASD at the time of Free Service.
  (ASD-Authorised Service Dealer)

Periodic Service Criteria			
Service	Days	Kms	
1st Free Service	30~45	500~750	whichever occurs earlier
2nd Free Service	240	4500~5000	
3rd Free Service	360	9500~10000	
Subsequent Paid services	120 Days from last Service	Every 5000 Km after previous service	

Availing all Free / Paid Services, replacing mandatory periodic parts & engine oil will entitle warranty eligibility.

PERIODIC MAINTENANCE & LUBRICATION CHART

Sr. No.	Activities / Check points	Recommended frequency - Service interval & Kms							
		Servicing	1st (Free)	2nd (Free)	3rd (Free)	4th	5th	6th	7th
		KMS	500 ~ 750	4500 ~ 5000	9500 ~ 10000	14500 ~ 15000	19500 ~ 20000	24500 ~ 25000	29500 ~ 30000
1.	Servicing with water wash	✓	✓	✓	✓	✓	✓	✓	✓
2.	Engine oil (Bajaj 10000 oil)	Top-up,R	R	Top-up	R	Top-up	R	Top-up	R
3.	Engine oil Filter	R	R		R		R		R
4.	Oil strainer	CL	CL		CL		CL		CL
5.	Air cleaner element** & air filter cover 'O' ring. Drain tube cleaning.	R					R		
6.	Inline fuel filter	R				R			R
7.	Inline fuel filter nylon hoses with quick connector	C,R					C,R		
8.	Spark plug clean & check gap	CL,A, R			CL,A		CL,A		R
9.	Valve tappet clearance	C, A				C, A			C, A
10.	Throttle body rubber duct (Sleeve) for hard resulting in loose fitment.	C,R				C,R	C,R	C,R	C,R
11.	Throttle body cleaning	CL		CL	CL	CL	CL	CL	CL
12.	Engine breather tube for cracks.	C,R			C,R	C,R	C,R	C,R	C,R
13.	EVAP system Hoses- check for cracks	C,R		C,R	C,R	C,R	C,R	C,R	C,R
14.	Radiator fins	C,R		C,R	C,R	C,R	C,R	C,R	C,R

Recommended frequency - Service interval & Kms									Remarks
8th	9th	10th	11th	12th	13th	14th	15th	16th	
34500 ~ 35000	39500 ~ 40000	44500 ~ 45000	49500 ~ 50000	54500 ~ 55000	59500 ~ 60000	64500 ~ 65000	69500 ~ 70000	74500 ~ 75000	
✓	✓	✓	✓	✓	✓	✓	✓	✓	Ensure to prevent water entry in Petrol tank, Silencer & electrical parts. Use caustic free detergent for washing.
Top-up	R	Top-up	R	Top-up	R	Top-up	R	Top-up	Use recommended BGO BS6 compliant engine oil only. Oil level window cleaning at every 10,000 km by petrol spray & nylon brush.
	R		R		R		R		Replace oil filter in 1st service & at every 10,000 km
	CL		CL		CL		CL		Oil strainer cleaning at the time of oil change.
	R				R				Replace viscus filter at every 20,000 km No Cleaning
		R			R			R	Replace at every 15,000km
	C,R				C,R				Replace if required
	CL,A		CL,A		R		CL,A		Replace at every 30,000 km
		C, A			C, A			C, A	
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	Replace if required
CL	CL	CL	CL	CL	CL	CL	CL	CL	Clean at every 5,000 km with recommended throttle body cleaning agent.
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	Replace if required
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	Replace if found cut / damaged
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	If found damaged, replace it

PERIODIC MAINTENANCE & LUBRICATION CHART

Sr. No.	Activities / Check points	Recommended frequency - Service interval & Kms							
		Servicing	1st (Free)	2nd (Free)	3rd (Free)	4th	5th	6th	7th
		KMS	500 ~ 750	4500 ~ 5000	9500 ~ 10000	14500 ~ 15000	19500 ~ 20000	24500 ~ 25000	29500 ~ 30000
15.	Check Coolant level in expansion tank / Hose clamp adjustment	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
16.	Coolant & Radiator hoses	Replacement at every 30000 km or 3 year (whichever occurs earlier)							
17.	Engine foundation silent bushes for cracks	C,R			C,R		C,R		C,R
18.	Silencer drain hole cleaning	CL			CL	CL	CL	CL	CL
19.	Water Pump seals	R							
20.	Wiring harness connections, routine & Conduit / PVC sleeve inspection.	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T
21.	Battery , connections & health by load tester. +ve terminal cap fitment.	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T
22.	Ignition switch contacts cleaning	CL,L			CL,L	CL,L	CL,L	CL,L	CL,L
23.	HT coil connections.	C,T		C,T	C,T	C,T	C,T	C,T	C,T
24.	Starter motor & starter relay connections	C,T		C,T	C,T	C,T	C,T	C,T	C,T
25.	Check fault code, Clear fault history, Update latest hex file if applicable	C	C	C	C	C	C	C	C
26.	Sealed Drive chain wear**- Clean, Lubricate & adjust. Replace if required	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A
27.	Drive chain link lock	R					R		

Recommended frequency - Service interval & Kms									Remarks
8th	9th	10th	11th	12th	13th	14th	15th	16th	
34500 ~ 35000	39500 ~ 40000	44500 ~ 45000	49500 ~ 50000	54500 ~ 55000	59500 ~ 60000	64500 ~ 65000	69500 ~ 70000	74500 ~ 75000	
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	Coolant top up if required Use BAJAJ Koolex coolant only.
Replacement at every 30000 km or 3 year (whichever occurs earlier)									
	C,R		C,R		C,R		C,R		Replace if required
CL	CL	CL	CL	CL	CL	CL	CL	CL	
	R								
C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	Damaged conduit / PVC sleeves protection by applying electrical tape film
C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	C,A,L,T	Apply petroleum jelly on battery terminals. Use midtronics battery tester
CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	Use recommended WD40 spray
C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	
C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	
C	C	C	C	C	C	C	C	C	
CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	CL,L,A	During 1st free service use OKS spray for chain cleaning without removing chain from vehicle.•During other services clean chain with Diesel+SAE 90 oil ratio of 50:50 & lubricate by SAE 90 oil.(Customer to use OKS chain lub spray at every 500 kms)
	R				R				

Sr. No.	Activities / Check points	Recommended frequency - Service interval & Kms							
		Servicing	1st (Free)	2nd (Free)	3rd (Free)	4th	5th	6th	7th
		KMS	500 ~ 750	4500 ~ 5000	9500 ~ 10000	14500 ~ 15000	19500 ~ 20000	24500 ~ 25000	29500 ~ 30000
28.	Side stand pivot pin	C,L					C,L		
29.	Steering play	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
30.	Steering stem bearing & Cap steering bearing (Plastic)**	C,CL,L			C,CL,L		C,CL,L		C,CL,L
31.	Front fork oil & seal	C,R	C,R	C,R	C,R	C,R	C,R	C,R	R
32.	Step-pillion LH & RH (Ball & Plate)	CL,L		CL,L	CL,L	CL,L	CL,L	CL,L	CL,L
33.	Swing arm NRB for more play	L							
34.	Brake pads for wear limit.	C,R	C,R	C,R	C,R	R	C,R	C,R	R
35.	Check source of leakages if any in the brake system. Check Front & rear brake hose condition. Check Brake fluid level and top up, if needed.	C,A,R	C,A,R	C,A,R	C,A,R	C,A,R	C,A,R	C,A,R	R
36.	Rear sprocket fasteners for looseness.	C,T	C,T		C,T		C,T		C,T
37.	Rear wheel rubber shock dampers for excess play.	C,R			C,R		C,R		C,R
38.	Fairing & windshield well nuts for rubber cracks	C,R			C,R	C,R	C,R	C,R	C,R
39.	Clutch cable free play adjustment	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
40.	Head light focus adjustment	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
41.	Check & confirm all bulbs / LED / switches working.	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A

Recommended frequency - Service interval & Kms									Remarks
8th	9th	10th	11th	12th	13th	14th	15th	16th	
34500 ~ 35000	39500 ~ 40000	44500 ~ 45000	49500 ~ 50000	54500 ~ 55000	59500 ~ 60000	64500 ~ 65000	69500 ~ 70000	74500 ~ 75000	
	C,L				C,L				Use recommended AP grease.
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
	C,CL,L		C,CL,L		C,CL,L		C,CL,L		Replace if required. Use Limaplex grease for lubrication
C,R	C,R	C,R	C,R	C,R	R	C,R	C,R	C,R	Replace oil and oil seal and dust seal in pair at every 30,000 km.
CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	Replace ball & plate, if required.
	L								Lubricate at every 40,000 km.
C,R	C,R	R	C,R	C,R	R	C,R	C,R	R	Replace at every 15,000 km. Lubricate pivot pin.
C,A,R	C,A,R	C,A,R	C,A,R	C,A,R	R	C,A,R	C,A,R	C,A,R	Check & Top up DOT 4 brake oil in every service.Replace DOT 4 brake oil & Master / Caliper seals at every 30,000 km.
	C,T		C,T		C,T		C,T		Use model wise torque values.
	C,R		C,R		C,R		C,R		Replace rear wheel rubber shock damper if required
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	Replace if required.
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	Replace cable if operation found hard.
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	Contact type switches if found sticky then use recommended WD40 spray

PERIODIC MAINTENANCE & LUBRICATION CHART

Sr. No.	Activities / Check points	Recommended frequency - Service interval & Kms							
		Servicing	1st (Free)	2nd (Free)	3rd (Free)	4th	5th	6th	7th
		KMS	500 ~ 750	4500 ~ 5000	9500 ~ 10000	14500 ~ 15000	19500 ~ 20000	24500 ~ 25000	29500 ~ 30000
42.	General lubrication – Clutch lever	L	L	L	L	L	L	L	L
43.	Tyre air pressure.	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
44.	Mirror position & joint firmness.	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A
45.	Mobile USB port	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R
46.	All fasteners tightness, few are, Front & rear axle,Swing arm axle,Engine foundation, Rider foot rest,Pillion stay	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T

****More frequent cleaning may be required while driving in dusty environment.**

C : Check, A : Adjust, CL : Clean, R : Replace, T : Tighten, L : Lubricate

Note : Periodic parts, Oil, Coolant, Filters, All types of greases, Cleaning agents, Cables, Wear & tear parts, Rubber 'O' rings / oil seals / pipes, Gaskets to be replaced as per Periodic Maintenance and Lubrication Chart are mandatory and the same are chargeable to customer.

Recommended frequency - Service interval & Kms									Remarks
8th	9th	10th	11th	12th	13th	14th	15th	16th	
34500 ~ 35000	39500 ~ 40000	44500 ~ 45000	49500 ~ 50000	54500 ~ 55000	59500 ~ 60000	64500 ~ 65000	69500 ~ 70000	74500 ~ 75000	
L	L	L	L	L	L	L	L	L	Use recommended AP grease.
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	Ensure model wise tyre air pressure.
C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	C,R	Charging OK to be checked at Engine start condition using LED USB light
C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	Use model wise torque values.

NON USE MAINTENANCE

Non-use maintenance is necessary if a vehicle remains off road for a longer duration (more than 15 days**). The correct and careful non-use maintenance carried out before storing the vehicle will prevent the vehicle from rusting and from such other non-operational damages like fire hazards.

- Clean the entire vehicle thoroughly.
- Empty the fuel from the fuel tank (if fuel is left in for a longer time, the fuel will break and gummy substance could clog the fuel system & fuel pipe).
- Remove spark plug & put several drops of engine oil into the cylinder. Kick engine over slowly a few times to coat cylinder wall with oil & install back spark plug.
- Set the vehicle on a box or a stand so that both wheels are raised off the ground.
- Spray oil on all unpainted metal surfaces to prevent rusting. Avoid getting oil on rubber parts or brake liners.
- Cover entire vehicle neatly. Make sure that storage area is well ventilated & free from any source of flames or spark.
- Fill 10% excess air pressure in both wheels.
- Do not apply oil on front brake disc, to prevent rusting. If the front brake disc rusts during storage, do not attempt to clean it with soap water. The rust will go off automatically during first few application of brake.

**** For Battery :**

a. Remove battery and keep it on wooden plank, in properly ventilated area.
b. Before taking the vehicle for use.

- Get the battery recharged from the Authorised Service Dealer / Battery Dealer.
- Apply petroleum jelly on battery terminals.

Preparation for regular use after storage :

- Follow daily safety checklist mentioned on page no 31.

DELIVERY CERTIFICATE

FRAME NO.: | | | | – | | | | – | | | | | | | | | |

ENGINE NO.: | | | | – | | | | – | | | | | |

Sold on.: _____

Customer's Name Mr/Mrs/Miss : _____

Address: _____ Contact No.: _____

I have taken possesion of motorcycle along with the following items.

1. Owner's Manual
2. 2 nos of key
3. Set of tools
4. First Aid Kit
5. Standard Accessories
6. Battery
7. Tyre

Make _____ Sr. No. _____

Fr Make _____ Sr. No. _____

Rr Make _____ Sr. No. _____

The Vehicle has been delivered to my satisfaction & I have understood all terms and conditions of warranty, service schedules & maintenance tips and shall abide by them.

Dealer Code :
Dealer Name :
Address :
Contact No. :

Customer's Signature (To be filled in by the dealer)

Important - Dealership should take customer sign & maintain the record of this (Delivery Certificate).

WARRANTY : SCOPE & LIMIT

Bajaj Auto Limited provides the following warranty in respect of the **"Pulsar NS 200 BS VI"** motorcycle manufactured by us.

Every possible care and precaution has been taken to ensure quality in respect of the material & workmanship in the vehicles manufactured by us. Bajaj Auto Limited will repair or replace at their Authorised Workshops, free of charge, part or parts there of as may be found, on examination, to have manufacturing defect within a period of 5 Years or 75,000 Kms., whichever is earlier from the date of sale subject to fulfillment of conditions stipulated in part A, B & C given here under

Note : Warranty is applicable for only first owner of vehicle.

Part A:

Warranty claims in respect of such items like shock absorbers, speedometers etc. though claimed through us, are subject to acceptance of the respective manufacturers. In all such cases the decision of the respective manufacturer will be final and binding.

Proprietory parts like tyres, tubes and battery are warranted by their respective manufacturers and should be claimed on them directly by the customer. Bajaj Auto Limited shall not be Liable to replace them though their dealer, however BAL Dealers will provide full assistance in referring such claims with respective manufacturer.

Bajaj Auto Limited undertake no liability in the matter of consequential loss or damage caused due to the failure of the parts. Delay, if any, at the repairing workshop in carrying out repair to vehicle shall not be a ground for extending the warranty period, nor shall it give any right to the customer for claiming any compensation for damages.

Bajaj Auto Limited reserves the right either to repair or replace the defective parts.

Where a defective part can be replaced by part/s of alternative brand/s, which are normally used by Bajaj Auto Limited in the course of manufacture, Bajaj Auto Limited reserves the right to carry out the replacement by a part or parts of any such alternative brand/s.

This warranty and any claim arising there,is subject to Pune jurisdiction only.

Part B:

No claim for exchange or repair can be considered unless the customer :

a. Ensures that immediately upon detection of the defect, he approaches any nearest BAL Authorised Vehicle Dealers & Recommended BAL Authorised Service Dealers with the concerned vehicle and enables him to remove and despatch the part / parts

attributing to the manufacturing defect to the Company.

b. Produces the Owner's Manual, in original, to enable that dealer to verify the details.

It must be expressly understood that claims forwarded directly to us by the owner / customer will not be entertained at all and such defective part/parts thus forwarded by them will lie at our factory at their own risk, and this warranty shall not be enforceable.

To avail benefits of warranty, following are mandatory

1. Availing of Initial 3 Free Services without lapse.
2. Availing paid services at subsequent 5000 kms. or 120 days from last service whichever is earlier without any lapse.
3. Availing of all services at the BAL Authorised Dealers & Recommended BAL Authorised Service Dealers.
4. Usage of only recommended engine oil **"Bajaj 10000 20W50"** at specified frequency for drain interval of 10,000 kms**.** & engine oil level top-up at 5000 kms.
5. Replacing mandatory periodic parts such as air filter, oil filter etc. as per periodic maintenance schedule.

Part C :

Further this warranty is NOT applicable to :

1. Normal maintenance operations like brake & clutch adjustments, cleaning of fuel system, engine tune-up or such other adjustments.
2. Parts subjected to normal wear & tear like Clutch Plates, Brake Shoes, Chain, Sprockets, Fork Oil Seal, Spark Plug, Control Cables, Brake Pads.
3. Replacement of bulbs & rubber components like grommets, 'O' rings, bellows as well as filters, packings, gaskets, fasteners etc.
4. Painted parts. Only blistering or peeling off of paint film are covered under warranty. Any defect arising out due to external damages or due to usage of protective covers /additional protective coatings adverse atmospheric conditions etc. are not allowed like under warranty.
5. All consumables like Engine oil, Fork oil, Brake Oil, Grease etc. are chargeable to customer.
6. Any defect arising due to above consumables not changed as per scheduled or if used other than the recommended one.
7. Never drive your bike through flooded roads or a flooded patch, as damages to the engine parts due to water entry is not covered under warranty.

8. All chrome plated parts are prone to rust or corrosion in coastal area or in acidic environment or due to neglected cleaning etc. However chrome film peeling is covered under warranty in general atmospheric conditions. Blue/ Yellow colouration of silencer near exhaust port is permissible and hence not covered under warranty.
9. Oxidation of unpainted/painted crankcase, cylinder block, cylinder head etc. in acidic environment or in a coastal area.
10. Parts of the vehicle that have been subjected to misuse, accident, negligent treatment OR which have been used in conjunction with parts & an equipment not manufactured or recommended for use by Bajaj Auto Limited, if found is the sole judgement of Bajaj Auto Limited, such use prematurely affects the performance and reliability of the vehicle.
11. Parts of the vehicle that have been altered and modified or replaced in unauthorized manner like use of wider tyres, loud silencers etc and which in the sole judgement of the Bajaj Auto Limited affects its performance and reliability.
12. **Vehicles which are not being serviced at recommended BAL authorized dealers as per the service schedule described or which have not been operated or maintained in accordance with the instructions maintained in the Owner's Manual.**
13. Vehicles used for any competition or race and/or for attempting to set up any kind of record.
14. Any failure arising due to use of adulterated or bad quality fuel.

    Parts affected due to bad fuel quality are not covered Under warranty.
15. If additional electrical accessories such as - Remote, Bigger horn, Musical brake light etc. fitted on vehicle.
16. If the vehicle has been used for commercial purpose like Taxi or any other means of commercial transportation.

Bajaj Auto Limited reserves the right to make any changes in design or to add any improvements on the vehicle at any time without incurring any obligation to install the same on a vehicle previously supplied and sold. Also, the conditions of this warranty are subject to alteration without any notice.

This warranty is the entire written warranty given by Bajaj Auto Limited for **"Pulsar NS 200 BS VI"** motorcycle' and no other dealer or its or his agent or employee is authorised to extend or enlarge this warranty.

BATTERY WARRANTY CARD

MAKE OF BATTERY : ..... MFG. CODE OF BATTERY :

BATTERY SR. NO.: BATTERY CHARGING DATE : _____

TYPE OF BATTERY : _____ VEHICLE SALE DATE : _____

NAME OF OWNER AND ADDRESS : _____

_____

TYPE OF VEHICLE : _____ REG. NO.: _____

FRAME NO.: _____ ENGINE NO.: _____

SERVICE RECORD

Sr. No.	Date	Age Mths.	Voltage	Remarks	Dealer's Stamp & Signature	* Code
1						
2						
3						
4						
5						
6						

*** Code For Remarks:**

AE : Electrical system needs attention.
IR : Insufficient running of vehicle.
CB : Cover broken.
BC : Broken Container.
PM : Poor maintenance.
BA : Battery abused.

Note : Customer should insist that "Service Record" must be filled by respective authorised battery dealer as proof of specified maintenance for easy settlement of claim, if any.

TO BE FILLED IN BY BATTERY DEALERS / DISTRIBUTORS IN CASE OF CLAIM

Name of Dealer & Code :_____

_____

Date of claim :_____ Battery Type :_____

Serial No. :_____ Date of Fitment :_____

Failure Mode (Please tick as applicable)

- **Loose connection**
- **Internal Short**
- **Plate Shedding**
- **Wrong Assembly**
- **Wrong Application**
- **Overcharge / Undercharge**
- **Reverse Charge**
- **Does not Hold Charge**
- **Left Lying Idle**
- **Terminal Corroded**

# Claim Accepted	**## Claim Rejected**

Details of Repair, if any_____

Note:

Please contact nearest respective authorised battery dealer for details immediately after purchase of vehicle.

USE ONLY BAJAJ GENUINE PARTS

pulsar NS200



We are committed to provide the best of sales & service experience, however should you require any additional assistance, please call our Call centre on the number given below.

 : 7219821111

Call charges are as applicable

Call centre timings :- Monday to Sunday
(09 : 00 am - 08 : 00 pm)

 Please download customer care app from **'Google play store'** and **'Apple store'** and book the vehicles for servicing and more on your phone.

E-mail : customerservice@bajajauto.co.in

Web Site : www.bajajauto.com

CIN : L65993PN2007PLC130076